

THE OASIS CABANA | model: OP-CAB08-PB

USE and CARE INSTRUCTIONS



**DO NOT RETURN THIS
PRODUCT TO THE STORE**

Please read the instruction manual carefully.

For Customer Care, Product Information and Problem Resolution, or to
order replacement parts, please contact CUSTOMER SERVICE
8a.m. to 5p.m. Mountain Standard Time:

(801) 924-2090

customerservice@redstartraders.com

Imported and distributed by:

Red Star Traders, LLC

1775 West 2300 South

Salt Lake City, Utah 84119

www.redstartraders.com

OPENING THE CABANA

	<p>STEP 1: OPENING THE FRAME</p> <p><u>* REQUIRES TWO (2) PERSON SET UP *:</u> Each person take position on opposing corners of the frame. Firmly grasp the upper pole and pull slowly outwards and away from each other to open the frame. (<u>WARNING:</u> DO NOT put out the down pole during this step.)</p>
	<p>STEP 2: LOCKING THE UPPER FRAME POLES INTO POSITION</p> <p>As the frame of the POP UP CABANA is opened, you must insure that the Frame Glide (part A) is locked completely into the push pin at the top of the each upper leg. You will hear a 'click' when it locks into OPEN position.</p>
	<p>STEP 3: EXTENDING THE LEGS</p> <p>Pull down the legs (DOWN POLE) until the push pin 'clicks' into upper pole. Make sure all four legs are locked in place.</p>

	<p>STEP 4: INSTALLING THE MOSQUITO NETTING</p> <p>The mosquito net comes as a continuous drape that wraps around the opening of the OASIS CABANA. You can close it to keep out the pests, or drape it open for added style. The top of the mosquito netting has a series of Velcro tabs that close to form the 'rings' of the draping. Close these tabs around the rope that runs along the inside. For added tension, pull the rope at the ends and tighten the connection.</p>
	<p>STEP 5: SECURING THE NETTING</p> <p>Locate the end straps on top corners of the mosquito netting. Tie the straps to the corners of the open frame to secure the netting.</p>
	<p>STEP 6: COMPLETING SET UP</p> <p>Pull the leg fabric down to tighten the Cabana body and fold the end cover over the triangular feet, secure in place with the Velcro. For added stability, secure the included stake pins into the ground and tighten the nylon rope to hold the Cabana in place.</p>

CLOSING THE CABANA

	<p>STEP 7: REMOVE THE NETTING</p> <p>Prior to closing the cabana, make sure to remove all of the netting material. Unhook the netting from the tie line by separating the Velcro.</p> <p>Store in a dry location.</p>
	<p>STEP 8: LOWER THE LEGS</p> <p>When closing the frame, the first step is to lower the legs. With two people (standing at opposite ends), push the stopper button to release each of the legs.</p> <p>Make sure you lower the legs <u>evenly</u> so as to prevent bending.</p>
	<p>STEP 9: COLLAPSING THE FRAME</p> <p>After the netting is removed and the legs are lowered, gently push the cabana together to collapse the frame.</p> <p>Use two people standing at opposite ends. Make sure to push evenly and together. Do not force and be careful not to bend the legs.</p>